



SHOWERS & EYEBATHS

Your Safety Demands Our Quality

INSTALLATION, MAINTENANCE & OPERATING INSTRUCTIONS **MOBILE SHOWER WITH EYEBATH – GPS12(electric)**

The unit is manufactured according to ANSI Z358.1 - 2009. It must be installed properly and in the correct location. Such equipment should be installed within 10 seconds reach if accident occurs; no closer than 3 metres or further than 15 metres. The area around and underneath the shower should provide good drainage, especially if there is a possibility of the water freezing. When equipment is located indoors waste water must be contained for subsequent safe disposal or there must be adequate drainage.

The mobile combined shower & eyewash requires a sound flat base. Please contact Showers & Eyebaths technical department for further advice should this be necessary.

INSTALLATION INSTRUCTIONS

1. Fill unit with clean potable water **BEFORE** any power is put to the unit.
2. Connect the power to the unit (leave for a minimum of 8hrs to warm the water if necessary) The immersion heater is NON HAZARDOUS. The power rating is 3Kw 220-240v 1Ph 50Hz and 1.7Kw 110-120v 1Ph 50Hz and pre set to 18 deg C.
3. Position unit in desired location with clear access.
4. Ensure brakes on the unit are applied and wheel chucks are positioned securely under each wheel.
5. Connect shower pipework to unit. Ensure shower valve is in upright position (i.e shower valve closed). Ensure insulation jacket (if purchased) is securely strapped on body of unit.
6. Unit is now ready to be used.
7. Test unit
8. If necessary - adjust the flow control on the eyebath which is located on the side of the eyebath until the water flow is correct

MAINTENANCE INSTRUCTIONS

1. Ensure operating valves are fully closed (This also ensures the pump is turned off).
2. Empty contained water regularly or after use.
3. Unit should be serviced and cleaned regularly at least every six months in order to ensure proper operation.
4. Clean the shower with non abrasive cleaners only and polish.
5. Remove overhead shower nozzle, inspect and disinfect every six months.
6. Remove eyebath nozzles, inspect and disinfect every six months.
7. Check all fastenings for torque every 6 months.
8. Check all electrical connections every 6 months.
9. Replace eyebath nozzles annually.

OPERATING INSTRUCTIONS

1. Pull shower handle downwards to operate shower. This action turns the pump on.
2. To turn off shower reset lever upwards. This action will turn the pump off.
3. Pull eyebath lid down to operate eyebath. This action turns the pump on
4. To turn off eyebath push lid upwards. This action will turn the pump off and protect the eyebath nozzles
5. After use seek medical assistance.

DO NOT TURN POWER ON IF THERE IS NO WATER IN THE UNIT.

World Class Manufacturers of Showers & Eyebaths

Showers & Eyebaths Services Ltd
Safety House, 23c Sandwash Close, Rainford Industrial Estate,
Rainford, Lancashire, WA11 8LY U.K.
Tel +44 (0) 1744 889677 Fax +44 (0) 1744 885663.
e-mail: sales@safety-showers.com www.safety-showers.com
Company Registration No. 3447603 Vat No: 703 9281 41



AMP 3 Framework Supplier